TELEDYNE 300EU (CO) CALIBRATION CHECK SHEET

DATE:	_ JULIAN DATE	B:	TECH INIT:	LOCATION:
PRE CAL FACTOR	<u>RS:</u>]	POST CAL FACTORS:	
CO OFFSET PPB	:		CO OFFSET PPB	:
CO SLOPE	:		CO SLOPE	<u>:</u>
SETTINGS:	_			
RANGE	☐ 1000 PPB	3		
DIACNOSTICS				
DIAGNOSTICS STABILITY	<u>:</u>	PPB	SAMPLE FLOW	: sccm
CO MEASURE	:		BENCH TEMP	: °C
CO REFERENCE	:		WHEEL TEMP	: °C
PRESSURE	:		OVEN TEMP	: °C
TIME LOG	PROCEDURAL STEPS			
	SWITCH FLAG OF	FLINE \square		
	ZERO CAL MODE			
	AIR FLOW: READ (CH1: 40)			
	SPAN FLOW:	READ (C	TH2: 0)	
	MEASURED ZERO): PPB	SET 300EU TO ZERO)
	SPAN CAL MODE			
	AIR FLOW: READ (CH1: 40)			
	SPAN FLOW:	READ (C	H2: 45)	
	MEASURED SPAN	:PPB	SET 300EU SPAN	N: (452) PPB 🗖
	ZERO MODE			
	AIR FLOW:	READ (C	'H1: 40)	
	SPAN FLOW: READ (CH3: 0)			
	ZERO CHECK 300	EU:PPB		
	LOG NEW CAL FACTORS \square			
	AMBIENT/AUTO (CAL MODE 🗖		
	SWITCH FLAG ON	ILINE 🗖		
ADDITIONAL NOT		· -		
				